



Figure 1. Physical Photo of AHVACPN5KV1MABT4

## FEATURES

- High precision
- High efficiency
- 4-Channels Output
- High output voltage stability
- Linear modulation of output voltage
- Overcurrent protection
- Short circuit protection
- Digital display for output voltage

## APPLICATIONS

The AHVACPN5KV1MABT4 is specifically designed for AC-DC conversion, transforming AC voltage into high DC voltage. It can be used for:

- X-ray Machine
- Spectral Analysis
- Nondestructive Inspection
- Semiconductor Manufacturing Equipment
- Particle Accelerator
- Capillary Electrophoresis
- Particles Injection

- Physical Vapor Phase Deposition
- Electrospinning Preparation of Nanofiber
- Glass/ Fabric Coating
- DC Reactive Magnetron Sputtering

## DESCRIPTION

To operate the high voltage power supply, first connect the AC 90~230V input, and then turn on the power. Ensure the potentiometer is set to "0" before opening the high voltage switch. Next, adjust the potentiometer in a clockwise direction while observing the digital display value. The output voltage = the display value. When the required voltage is reached, rotate the potentiometer lock in a clockwise direction to lock the potentiometer. This will prevent accidental adjustments to the potentiometer, which could alter the output voltage. High voltage connection wire is used for high voltage output.

## SAFETY PRECAUTIONS

To ensure safe operation, the high voltage power supply must be reliably grounded. Under no circumstances should the high voltage wire be touched unless the power supply is switched off and the load and internal capacitors are fully discharged. After switching off the



power supply, it is recommended to wait for at least 5 minutes to allow all capacitors to fully discharge.

The power supply should not be operated in a humid environment, and the operator should not be connected to ground. Although the power supply includes internal protection circuits, high voltage short circuits must be

avoided.

It is important to ensure that the circuit is properly insulated, particularly between the high voltage output and the surrounding environment, to prevent electric shock.

## SPECIFICATIONS

Table 1. Characteristics.

T<sub>A</sub> = 25°C, unless otherwise noted

Parameter	Symbol	Test Conditions	Min.	Typ.	Max.	Unit
AC Input Power Supply Voltage	V <sub>VPS</sub>		90	110	230	V <sub>AC</sub>
Input Power Supply Quiescent Current	I <sub>VPS_QC</sub>	I <sub>VOUT</sub> = 0mA VPS = 110V		≤70		mA
		I <sub>VOUT</sub> = 0mA VPS = 220V		≤50		mA
Input Power Supply Current at Full Load	I <sub>VPS_FL</sub>	I <sub>VOUT</sub> = 1mA VPS = 110V		≤220		mA
		I <sub>VOUT</sub> = 1mA VPS = 220V		≤110		mA
Input Voltage Regulation Ratio	ΔV <sub>OUT</sub> /ΔVPS	VPS = 90V ~ 230V		0.05		%
Output Voltage Range	V <sub>VOUT</sub>	I <sub>VOUT</sub> = 0 ~ 1mA	0		±5000	V
Output Current Range	I <sub>VOUTMAX</sub>	V <sub>VPS</sub> = 90V ~ 230V	0		1	mA
Output Load Resistance Range			$\frac{V_{VOUT}}{I_{VOUT}}$		∞	MΩ
Output Modulation Linearity			≤0.1			%
Output Voltage Temperature Coefficient	TC <sub>VOUT</sub>	V <sub>VPS</sub> = 90V ~ 230V V <sub>VOUT</sub> = ±5000V I <sub>VOUT</sub> = 1mA T <sub>A</sub> = -20°C ~ 55°C		≤0.01		%/°C
Output Voltage Range v.s. Temperature	V <sub>VOUT</sub> (T)	V <sub>VPS</sub> = 90V ~ 230V V <sub>VOUT</sub> = ±5000V I <sub>VOUT</sub> = 1mA T <sub>A</sub> = -20°C ~ 55°C	0.99V <sub>VOUT</sub>	V <sub>VOUT</sub>	1.01V <sub>VOUT</sub>	V



Parameter		Symbol	Test Conditions	Min.	Typ.	Max.	Unit
Output Voltage Drift	Short Term Drift	$\frac{ \Delta V_{VOUT}/V_{VOUT} }{\Delta t \text{ (min)}}$	$V_{VPS} = 90V \sim 230V$ $V_{VOUT} = \pm 5000V$		$\leq 0.05$		%/min
	Long Term Drift	$\frac{ \Delta V_{VOUT}/V_{VOUT} }{\Delta t \text{ (h)}}$	$I_{VOUT} = 1mA$ $T_A = -20^{\circ}C \sim 55^{\circ}C$		$\leq 0.05$		%/h
Mean Time Between Failure		MTBF			1M		h
Instantaneous Short Circuit Current at the Output		$I_{VOUT\_SC}$			$\leq 0.1$		mA
Load Regulation		$\frac{ \Delta V_{VOUT}/V_{VOUT} }{\Delta I_{VOUT}}$	$V_{VOUT} = \pm 5000V$ $I_{VOUT} = 0 \sim 1mA$		$\leq 0.05$		%/mA
Full Load Efficiency		$\eta$	$V_{VPS} = 90V \sim 230V$ $V_{VOUT} = \pm 5000V$ $I_{VOUT} = 1mA$		$\geq 70$		%
Operating Temperature Range		$T_{opr}$		-20		55	$^{\circ}C$
Storage Temperature Range		$T_{stg}$		-20		80	$^{\circ}C$
External Dimensions				350×304×125		mm	
				13.78×11.96×4.92		inch	
Weight					4000	g	
					8.82	lbs	
					141.10	Oz	



PANNEL INSTRUCTIONS

Front Panel




Figure 2. Front Panel

1. CH1 High Voltage Output ON/OFF Switch.
2. Display the CH1 output voltage: Digital display for the output voltage. The actual output voltage = the reading.
3. CH1 HV adjustment: 10-turn potentiometer for adjusting output voltage. Rotate it clockwise to increase the output voltage, and the potentiometer resistance = the corresponding scale  $\times 20\Omega + N \times 2k\Omega$ . The number of turns (N) is shown in the frame above the scale. For example, as Figure 2 shows, when the scale is 10, and the frame above the scale shows 1 (2k $\Omega$ ), then the resistance =  $10 \times 20\Omega + 1 \times 2k\Omega = 2.2k\Omega$ , and the like.
4. CH2 High Voltage Output ON/OFF Switch.
5. Display the CH2 output voltage: Digital display for the output voltage. The actual output voltage = the display value.
6. CH2 HV adjustment: 10-turn potentiometer for adjusting output voltage. Rotate it clockwise to increase the output voltage, and the potentiometer resistance = the corresponding scale  $\times 20\Omega + N \times 2k\Omega$ . The number of turns (N) is shown in the frame above the scale. For example, as Figure 2 shows, when the scale is 10, and the frame above the scale shows 1 (2k $\Omega$ ), then the resistance =  $10 \times 20\Omega + 1 \times 2k\Omega = 2.2k\Omega$ , and the like.
7. CH3 High Voltage Output ON/OFF Switch.
8. Display the CH3 output voltage: Digital display for the output voltage. The actual output voltage = the display value.
9. CH3 HV adjustment: 10-turn potentiometer for adjusting output voltage. Rotate it clockwise to increase the output voltage, and the potentiometer resistance = the corresponding scale  $\times 20\Omega + N \times 2k\Omega$ . The number of turns (N) is shown in the frame above the scale. For example, as Figure 2 shows, when the scale is 10, and the frame above



the scale shows 1 (2kΩ), then the resistance = 10×20Ω+1×2kΩ=2.2kΩ, and the like.

- 10. CH4 High Voltage Output ON/OFF Switch.
- 11. Display the CH3 output voltage: Digital display for the output voltage. The actual output voltage = the display value.
- 12. CH4 HV adjustment: 10-turn potentiometer for adjusting output voltage. Rotate it clockwise to increase the output voltage, and the potentiometer resistance = the corresponding scale × 20Ω+N × 2kΩ. The number of turns (N) is shown in the frame above the scale. For example, as Figure 2 shows, when the scale is 10, and the frame above the scale shows 1 (2kΩ), then the resistance = 10×20Ω+1×2kΩ=2.2kΩ, and the like.

Back Panel




Figure 3. Front Panel

- 13. AC Main Power ON/OFF Switch.
- 14. Input connector: AC input 90 ~ 230V 50/60Hz connector.
- 15. Output ground: high voltage power supply output ground terminal.
- 16. CH4 HV output: 1m long connection wire outputs –5kV and 1mA.
- 17. CH3 HV output: 1m long connection wire outputs –5kV and 1mA.
- 18. CH2 HV output: 1m long connection wire outputs 5kV and 1mA.
- 19. CH1 HV output: 1m long connection wire outputs 5kV and 1mA.



### TESTING DATA

Test conditions:  $V_{VPS} = 90 \sim 230V_{AC}$ ,  $T_A = 25^{\circ}C$ ,  $R_{LOAD} = 5M\Omega$

The measured output voltage,  $V_{OUT}$ , corresponding to the control port input voltage,  $V_{CTRL}$ , is shown in Figure 4.




Figure 4.  $V_{CTRL}$  vs.  $V_{OUT}$

### NAMING PRINCIPLE




Figure 5. Naming Rules of AHVACPN5KV1MABT4





### DIMENSIONS

I. Dimension of the leads.



Figure 6. Leads of AHVACPN5KV1MABT4

Lead Wires	Diameter		Length	
	mm	inch	mm	inch
Thick brown lead wire	4.5	0.177	1000	39.370
Power cord	6.5	0.256	1800	70.866



II. Outline Dimensions.




Figure 7. Outline Dimensions

ORDERING INFORMATION

Part Number	Buy Now
AHVACPN5KV1MABT4	* *

NOTICE

1. It is important to carefully read and follow the warnings, cautions, and product-specific notes provided with electronic components. These instructions are designed to ensure the safe and proper use of the component and to prevent damage to the component or surrounding equipment. Failure to follow these instructions could result in malfunction or failure of the component, damage to surrounding equipment, or even injury or harm to individuals. Always take the necessary precautions and seek professional assistance if unsure about proper use or handling of electronic components.
2. Please note that the products and specifications described in this publication are subject to change without prior notice as we continuously improve our products. Therefore, we recommend checking the product descriptions and specifications before placing an order to ensure that they are still applicable. We also reserve the right to discontinue the production and delivery of certain products, which means that not all products named in this publication may always be available.
3. This means that while ATI may provide information about the typical requirements and applications of their products, they cannot guarantee that their products will be suitable for all customer applications. It is the responsibility of the customer to evaluate whether an ATI product with the specified properties is appropriate for





their particular application.

4. ATI warrants its products to perform according to specifications for one year from the date of sale, except when damaged due to excessive abuse. If a product fails to meet specifications within one year of the sale, it can be exchanged free of charge.
5. ATI reserves the right to make changes or discontinue products or services without notice. Customers are advised to obtain the latest information before placing orders.
6. All products are sold subject to terms and conditions of sale, including those pertaining to warranty, patent infringement, and limitation of liability. Customers are responsible for their applications using ATI products, and ATI assumes no liability for applications assistance or customer product design.
7. ATI does not grant any license, either express or implied, under any patent right, copyright, mask work right, or other intellectual property right of ATI.
8. ATI's publication of information regarding third-party products or services does not constitute approval, warranty, or endorsement.
9. ATI retains ownership of all rights for special technologies, techniques, and designs for its products and projects, as well as any modifications, improvements, and inventions made by ATI.
10. Despite operating the electronic modules as specified, malfunctions or failures may occur before the end of their usual service life due to the current state of technology. Therefore, it is crucial for customer applications that require a high level of operational safety, especially in accident prevention or life-saving systems where the malfunction or failure of electronic modules could pose a risk to human life or health, to ensure that suitable measures are taken. The customer should design their application or implement protective circuitry or redundancy to prevent injury or damage to third parties in the event of an electronic module malfunction or failure.